

Product Specifications

FlashLink VU In-Transit Logger

Recording Period	15 Days
Logging Interval	5 Min and 40 Sec
Measurement Range	-40°F to 122°F (-40°C to 50°C)
Temperature Resolution	0.1°F/°C
Temperature Accuracy	±1.0°F from 14°F to 77°F (±0.5°C from -10°C to 25°C); ±2.0°F above 77°F (±1.0°C above 25°C) ±2.0°F below 14°F (±1.0°C below -10°C)
Data Capacity	3823 points
Data Download Time	5 seconds typical for 3823 points
Alarms/Settings	High 36° F (2°C), Low 28° F (-2°C) Delay Start 30 min, Alarm Delay 30 min
Battery	Coin Cell Lithium Battery
Logger Dimensions	1.962" x 3.423" x .575" (50mm x 87mm x 15mm)
Casing	ABS plastic
Logger Weight	1.6 oz. (45.36 grams)
Shock Resistance	Withstands 3-foot (1 meter) drop to hard surface
Certification	CE Mark, NIST traceable, RoHS compliant
Display	°F Scale on LCD, Red LED Alarm
IP Rating	IP56
Storage conditions	-4°F to 122°F (-20°C to 50°C) 0% to 95% RH w/o condensation
System Requirements	Windows PC with current operating system, FlashLink Data Manager software, Adobe Reader
Download Requirements	8-Pin to USB Adapter

Patent No. 6,088, 514

DeltaTrak manufactures products under an ISO 9001:2015 registered quality management system

FlashLink VU In-Transit Logger

SHIPPER INSTRUCTIONS

- Fill out the shipping label on the logger.
- Press and hold the green START button until the active mode icon (🔴) flashes on the LCD and temperature reading appears.
- Use adhesive strips to place logger on top of pallet or package to be shipped. Fold bottom half of card down over edge of box to indicate location of logger.

INSTRUCCIONES DEL CARGADOR

- Rellene la etiqueta de envío en el registrador.
- Presione y mantenga presionado el botón verde START hasta que el icono de modo activo (🔴) y la temperatura aparezca en la LCD.
- Utilice la cinta adhesiva para colocar el termógrafo arriba de la paleta o paqueta por entregar. Doble la parte baja de la tarjeta hacia el borde de la caja para indicar el lugar del termógrafo.

RECEIVER INSTRUCTIONS

ATTENTION DATA LOGGER HERE

DOWNLOAD LOGGER

- Remove logger from card.
- Press START button to display trip statistics and alarm status. A new statistic is shown each time START button is pressed.
- Connect logger to PC with 8-Pin to USB Adapter, or to a CT Graphics Printer. Downloading the logger will automatically stop the logger.

NOTE: Download FlashLink Data Manager software (www.deltatrak.com/support/software-drivers). For 8-Pin to USB Adapter, visit www.deltatrak.com/contact-us or call 800-962-6776 or 925-249-2250.

This instrument is under lease. NOT FOR SALE. Property of DeltaTrak, Inc. Please return instrument via US Mail. US Patent No. 6,088,514/6,142,258

MODEL 20862-01
15-DAY HI ALARM 36°F/2°C
LO ALARM 28°F/-2°C

DeltaTrak
1238 Doker Drive, Modesto, CA 95351 | 800-962-6776 | 925-249-2250 | www.deltatrak.com

3238 16C1

Model	High Alarm	Low Alarm	Delay Start	Alarm Delay
20862-01	36°F (2°C)	28°F (-2°C)	30 Min	30 Min

- Accepted by most receivers
- Consolidate logger inventory with one brand for all shipments
- Hi/low alarms programmed for proteins and other frozen products
- Mounted on high-visibility locator card
- Trip history statistics available on LCD
- Patented Shadow Log feature guarantees data even if the operator fails to start the unit
- Download data to PC as secure PDF report or print chart using CT Graphics printer



SS_20862-01_20D1