



FlashLink®

RTL Prime In-Transit Logger

Get quick access to download PDF reports via onboard USB!

Know the temperature and location of your products at any time! Track deliveries using a cloud based service and see real-time route information and conditions in a shipping container and truck. Flight mode allows use on airplanes.

The RTL Prime In-Transit Logger sends data to a web account where it's always available, even before a shipment reaches the receiving dock. Reliable up-to-the-minute information is accessed with a standard web browser, using a PC or any internet-ready device. Alerts are automatically sent when out-of-range conditions occur.

- Monitors location and temperature
- Data transmitted via GSM cellular networks
- 2-in-1 backup onboard PDF logger feature
- No need to open vehicle doors to access information
- 24/7 cloud service to view and analyze data remotely
- Make immediate cold chain management decisions
- Data stored in the cloud for traceability, audits, HACCP, and FSMA compliance
- Reroute trucks when necessary
- Customize settings for high/low alarm limits
- 12 month battery shelf life

Call 800-962-6776

