Installation Instructions



FlashPDF Software Download and Installation

FlashPDF automatically creates an Adobe® PDF report file from the recorded data on any FlashLink data logger and stores it on your Windows PC. Once installed on your PC, FlashPDF runs automatically when a logger is connected through the USB adapter. You can email or print the PDF report for permanent record-keeping.

- Open a web browser and go to www.deltatrak.com website.
- 2. Locate the main menu at the top of the web page under the DeltaTrak company logo and then select **Support** in the menu.
- Scroll down to Software and Drivers in the menu and Click this selection.
- Select your geographic location on the map shown
- Along the left side of the page, scroll down the page to FlashPDF and then Click on FlashPDF
- **6.** Fill out the form and Click on the **Submit** button at the bottom of the form.
- 7. On the next screen, please take note of the

- phone number for Technical Support and Click on **Download** in the center of the screen.
- On the next screen, select the location where you will save the download file and Click Save to start your download.
- When the download is completed, navigate to the location on your computer where you saved the download file.
- Double Click the FlashPDF.zip file. A new window will open.
- Right Click on the FlashPDF setup.exe file and select Run as administrator.
- **12.** When the Welcome screen is displayed, the installation process will guide you through the remaining steps for the software installation.

Help File

Please read the help file before getting started. The Help system can be accessed by a single right click on the FlashPDF lightning bolt icon in the system tray and selecting "About" from the pull down menu.

Operating System Requirements

Windows XP, Windows 7, 32 bit or 64 bit computers.

Hardware Requirements

400 MHz minimum CPU, 512 MB RAM Memory, 500GB Hard Drive, One USB Port 2.0 or 3.0.

Device Compatibility

Any FlashLink Data loggers.

Other Software Requirements

Adobe Acrobat Reader 8.0 or greater



